

TOWER HEATER

PE-HE019

User Manual

English 02

日本語 06

THANK YOU

FOR BEING OUR CUSTOMER

Your purchase is truly appreciated!
We hope you are over-the-moon with our product!

L A N G U A

IMPORTANT SAFETY INSTRUCTIONS

Intended Use

- This heater is not intended for use in bathroom, laundry areas and similar moist indoor locations. Never locate heater where it may fall into a bathtub or other water container.
- Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.
- The output of this heater may vary and its temperature may become intense enough to burn exposed skin. Use of this heater is not recommended for persons with reduced sensitivity to heat or an inability to react to avoid burns.

Related to Use

- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surface. Keep combustible materials such as furniture, pillows, bedding, papers, clothes and curtains at least 3 feet (0.9m) from the front of the heater.
- Extreme caution is necessary when this heater is used by or near children or invalids and whenever the heater is left operating and unattended.
- Do not operate any heater with a damaged cord or plug or after the heater malfunctions, has been dropped or damaged in any manner. Discard heater or return heater to authorized service facility for examination, electrical or mechanical adjustment, or repair.
- Do not use the heater outdoors.
- To prevent a possible fire, do not block air intakes or exhaust in any manner.
- Do not use on soft surface, like a bed, where openings may become blocked.
- A heater has hot and arcing or sparking parts inside. Do not use it in the areas where gasoline, paint, or flammable liquids are used or stored.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- Always unplug the heater when not in use.
- Never tamper with the heater or attempt to fix it. Any tampering with, or modification of this product can result in serious injury, death, or fire, risk of electric shock. Do Not open. No user serviceable parts inside.
- DO NOT remove product labels that contain warnings or safety instruction.
- Before cleaning, or storage, or when not in use, turn the heater off and unplug it.

Electrical Safety

- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Do not route cord under furniture or appliances. Arrange cord away from traffic area and where it will not be tripped over.
- To prevent overloading a circuit, do not plug the heater into a circuit that already has other appliances working.
- It is normal for the plug to feel warm to the touch; however, a loose fit between the AC outlet (receptacle) and plug may cause overheating and distortion of the plug. Contact a qualified electrician to replace loose or worn outlet.
- To disconnect the heater, first turn it off, then remove plug from outlet. Never pull by the cord.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or

- releasable power tap (outlet/power strip).
- If your home has aluminum wiring, have a licensed electrician check your receptacle's connections. When using a 1500-watt heater, aluminum wire connections can cause a safety issue.

Specifications

Power	Hot Air (1500 Watts) Warm Air (1000 Watts)
Voltage	120V
Current	60Hz
Water Tank Capacity	1L

KNOWING YOUR TOWER HEATER

Remote Control

- Basically the buttons are the same as the control panel.
- The button is used to **start/stop misting**.

USING YOUR TOWER HEATER

- Place the heater on a level and flat surface.
- Plug the heater into an electrical outlet.
- Press the ON/OFF switch at the back to "1" to enter standby mode.
- Tap on the heater/remote control to start working, tap again to stop.

Note:

- If the PTC is working, the heater will work for another 30s after stop working, then enters standby mode.
- No operation within 1 min, the screen will be auto-off. Tap any button to wake up the screen.

Misting

- Remove the tank cover and take out the water tank.
- Add water to the tank and put it back in place.
- Press to start/stop misting.

- This function is independent and can be operated without the PTC working.
- Always drain the water tank and unplug the unit if it is idle for a long time.

Heating Levels

- Natural: The air output is in current ambient temperature.
- Warm: The air output is warm air.
- Hot: The air output is hot air.

Temp Settings

- Press or to start setting output temperature (50-95°F, default: 77°F).
- When the ambient temperature reaches the desired temperature, the PTC stops working. When the ambient temperature falls below the desired temperature, the PTC resume working automatically.

CLEANING AND STORAGE

WARNING: Always unplug the heater and wait until the heater cools down before cleaning and storing it!

- Do not clean the heater body with water.
- Wipe down the body with some neutral detergent with a soft cloth and wipe dry.
- Do not use any solvent such as gasoline.
- After each cleaning, wait until the heater gets dry before using or storing.
- Place the heater back in the packing box to protect it from dust. Store it in a cool, dry location.

TROUBLESHOOTING

The heater fails to power on.

- Make sure the heater is securely plugged into the outlet.
- Place the heater on a level and flat surface.
- Press the heating level button to cancel temp settings. Set the temp above the ambient temp.

The heater cannot be turned off.

- Press the Power ON/Standby button to stop the heater from working.

Misting is not working.

- Add enough water to the tank.

JP

安全上の重要事項

使用目的

- このヒーターは浴室、洗濯エリアなどの湿度の高い室内環境ではご利用いただけません。また、浴槽などの水が溜まる場所に落下する可能性がある場所にはヒーターを設置しないでください。

- このヒーターは、説明書に記載されている使用方法以外では使用しないでください。推奨されない方法で使った場合、火災、電気ショックや怪我などを引き起こす可能性があります。

- このヒーターの出力が一定ではなく、火傷を引き起こす高温になる可能性があります。熱を届くにくい方や火傷を避けるための着払い対応がございません。このヒーターで「使用をお勧めしません」。

使用に関して

- このヒーターが作動している間は、火傷の恐れがあるため、高温エリアに素肌が触れないようにしてください。家具、枕、寝具、衣類やカーテンなどの可燃性のものは、本体前面から90cm以上は離してください。

- このヒーターを子供や病人が使用したり、子供や病人の周りで使用したりする場合、または無人環境でヒーターを作動させる場合には、十分に注意が必要です。

- コードやプラグが破損していたり、製品に誤作動が起こったりした場合、または製品が落下・損傷した場合は、絶対にヒーターを使用しないでください。製品を処分するが、認定サービスセンターに点検、修理をご依頼ください。

- 絶対に屋外で使用しないでください。

- 火災を防ぐため、いかなる場合も送風口と排気口は塞がらないようにしてください。

- 開口部が塞がれてしまう可能性があるため、ベッドなどの狭い場所で使用しないでください。

- 製品に高温のパーツ/スワブ部品が内蔵してあります。ガソリンや塗料などの可燃性液体が使用/保管

- 置されている場所では使用しないでください。

- 電気ショックや火災・破損などを防ぐため、この通気・排気口にも異物を入れないようにしてください。

- 使用しない時は常にコンセントを外してください。

- ヒーターを改造したり修理しようとししないでください。火事や電気ショックにより、深刻な怪我や死を招く可能性があります。また、お客様自身で修理できる部品はないため、製品を分解し本体を壊すことは絶対にしないでください。

- 警告や安全の手引書のラベルに則さないでください。

- お手入れや収納の前、または使用していない時は、必ず製品の電源を落とすコンセントを抜いてください。

電気的安全性

- ケーブルの下に電源コードを置かないでください。マッドラグなどで電源コードを覆わないでください。家具や電化製品の下にコードを置かないでください。つまり防止のため、電源コードは家の断縁を避けて配置してください。

- ブレーカーが落ちるのを避けるために、他の家電を使用しているサーキットで、ヒーターを使用しないでください。

- プラグがあたかくなるのは故障ではありません。しかし、コンセントとプラグの結合が緩い場合、過熱とプラグの変形を引き起こす可能性があります。適切な電気技術者に連絡し、不適切なコンセントは新しいものに取替えてください。

- ヒーターの断縁を外すときは必ず電源を切って、コンセントからプラグを外してください。コード部分を引っ張らないようにしてください。

- 必ず直接コンセントに繋いでください。延長コードやパワータップは絶対に使用しないでください。

- ご家庭の配線がアルミワーム配線の場合、適切な電気技術者にコンセントの接続状態を確認していただく必要があります。アルミワーム配線に1200ワットのヒーターを使用し、安全性の問題が生じる可能性あります。

仕様

電力	熱風(1200ワット) 温風(800ワット)
電圧	100V
電流	50/60Hz
水タンク容量	1L

タワーヒーターについて

本体

リモートコントローラ

- 基本的にはコントロールパネルのボタンと同じです。
- はミストを開始/停止するためのボタンです。

タワーヒーターの使用について

- ヒーターを平らな場所に設置してください。
- ヒーターの電源コードをコンセントに差し込んでください。
- 背面のオン/オフボタンを押し、「1」のスタンバイモードにする。
- 本体もしくはリモートコントローラの ボタンを押してヒーターを作動/停止させてください。

備考:

- PTC が作動中は、停止ボタンを押した後もヒーターは 30 秒間動作を続け、その後スタンバイ

モードに入ります。

- 1 分間無操作の場合画面表示は自動的にオフになります。再び画面を表示させるには、上記のボタンを押してください。

ミスト

- タンクカバーを外し、水タンクを取り出します。
- タンクに水を追加し、元の位置に戻します。
- を押して、ミストを開始/停止します。

- ミストは独立しており、PTC が機能しなくても操作できます。
- 長期間使用しない場合は、必ず水タンクを空にし、ユニットのプラグを抜いてください。

ヒーターレベル

➡ ナチュラ: その時の周辺温度の空気が出ます。

※ 中温: 温かい空気が出ます。

※ 高温: 熱い空気が出ます。

温度設定

- ボタンもしくは ボタンを押して温度を設定します。(10-35°C、規定: 25°C)
- 周辺温度が設定温度に達した時、PTC が止まります。周辺温度が設定温度以下になると、PTC は再び自動的に作動し始めます。

お手入れ/保管方法

警告: お手入れ/保管の前に、必ず電源プラグをコンセントから引き抜き、本体が冷めるのを確認してください！

- ヒーター本体を水で洗わないでください。

- 柔らかい布巾と中性洗剤で本体の汚れを拭き取った後乾いた布巾で拭いてください。

- ガソリンなどの溶剤は使用しないでください。

- お手入れ後は必ずヒーターが乾くのを待ってから使用/保管してください。

- 埃を防ぐため、本体は梱包箱に戻し、湿気のない涼しい場所に保管してください。

トラブルシューティング

ヒーターの電源がつかない。

- ヒーターの電源プラグがしっかりとコンセントに差込が確認してください。
- ヒーターを平らな場所に設置してください。

- ヒーターレベルボタンを押して温度設定をキャンセルし、周辺温度より高く温度設定してください。

ヒーターの電源が落ちない。

- 電源オン/スタンバイボタンを押して止めてください。

ミストは機能していません。

- タンクに十分な水を追加します。

WARRANTY

Thanks for choosing Paris Rhône TOWER HEATER.

This product is covered with Paris Rhône product and labor warranty for 12 months from the date of its original purchase.

The warranty will not apply in cases of:

- Accident, misuse, or repairs performed by unauthorized personnel.
- Any unit that has been tampered with or used for commercial purpose.
- Normal wear and tear of wearable parts.
- Use of force, damage caused by external influences.
- Damage caused by non-observance of the User Manual, e.g. connection to an unsuitable mains supply or non-compliance with the instructions.
- Partially or completely dismantled appliances.
- Defects caused by or resulting from damages from shipping or from repairs, service, or alteration to the product or any of its parts that have been performed by a repair person not authorized by Paris Rhône.

We can only provide after sales service for products that are sold by Paris Rhône or Paris Rhône authorized retailers and distributors.

If you have purchased your unit from a different place, please contact your seller for return and warranty issues.

※ Please have your invoice and order ID ready before contacting Customer Support.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

WEEE Compliance

Correct Disposal of This Product (Waste Electrical & Electronic Equipment)

(Applicable in countries with separate collection systems)

This marking on the product, accessories or literature indicates that the product and its electronic accessories should not be disposed of with other household waste at the end of their working life. To prevent possible harm to the environment or human health from uncontrolled waste disposal, please separate these items from other types of waste and recycle them responsibly to promote the sustainable reuse of material resources. Household users should contact either the retailer where they purchased this product, or their local government office, for details of where and how they can take these items for environmentally safe recycling. Business users should contact their supplier and check the terms and conditions of the purchase contract. This product and its electronic accessories should not be mixed with other commercial wastes for disposal.

Questions or Concerns?
support@parishh.com