

Please be sure to read the enclosed Shark® Owner's Guide prior to using your unit.

Shark® Navigator™ Pet Pro


ZERO-M™
CLEANER HEAD

QUICK START GUIDE

WHAT'S INSIDE

- A Vacuum
- B Handle & Hose
- C Wand
- D Hose Holder
- E Duster Crevice Tool
- F Upholstery Tool
- F Dusting Brush


ASSEMBLY





NOTE: For proper operation, ensure all parts are firmly **CLICKED** into place.

EMPTYING THE DUST CUP

Empty the dust cup after each use.



MAINTENANCE



Use a coin to turn locks, then lift cover open. Clear the debris intake.

Shark's Zero-M™ self-cleaning brushroll delivers non-stop hair removal. Remove any blockages or objects stuck on or around the brushroll.

If any hair is wrapped around brushroll, extending cleaning time will help it clear.

2 WAYS TO CLEAN


FLOOR CLEANING

SUCTION CONTROL

Adjust your suction depending on your floor type.

MIN: to reduce suction and increase maneuverability on carpets.

MAX: to increase suction on bare floors.




1

HARD FLOOR

Press switch to I for hard floor surfaces.


OR



2

CARPET


Press switch to II for low and high pile carpet cleaning.



3

To engage brushroll, step on floor nozzle and tilt handle back.



ABOVE-FLOOR CLEANING



1

To clean above-floor areas, remove the handle from the wand. For even more reach, remove the wand from the pod.

OR



2

Attach desired cleaning accessory to handle or wand.

For additional parts and accessories visit sharkaccessories.com

For questions or to register your product, contact us at 1-800-798-7398 or visit us online at sharkclean.com



@sharkcleaning