















 THE FITNESS EARBUDS USER MANUAL				TABLE OF CONTENTS INTRODUCTION UNIT AT A GLANCE FEATURE AT A GLANCE QUICK START GUIDE CHARGING YOUR DEVICE FUNCTIONS SOUND PROFILES AWARENESS MODE HOW TO CHANGE GEL TIPS HOW TO CHANGE STABILIZERS GEL TIPS PERFECT FIT STABILIZERS THE PERFECT FIT SAFETY GUIDELINES FAQ & ADDITIONAL RESOURCES SUPPORT LIMITED WARRANTY SPECIFICATIONS 12345678910111213131313	INTRODUCTION Welcome to your new Raycon Fitness Earbuds! We are Raycon. We create carefully crafted wireless audio products for go-getters who need tech that keeps up with them. We teamed up with expert engineers, leading taste-makers, and platinum artists to design products you'll love to use. We believe in the early risers and the one-more-milers of the world. Premium audio, inspired by you. Before using your product, we strongly encourage you to fully read through this user guide. You can also visit our support center at www.rayconglobal.com/support. This web page has more specific guidelines and helpful videos for you to navigate your product. For the best performance, charge fully before first use. Pairing ID: The Fitness Earbuds International Manual For international versions of the manual, please visit www.rayconglobal.com/support.	UNIT AT A GLANCE 1. Touch Controls 2. LED Indicator /Microphone 3. Perfect Fit Stabilizer 4. Gel Tips 5. Charging Port 6. Wireless Charging Capsule 7. Battery Indicator  12	FEATURES AT A GLANCE  PERFECT FIT STABILIZERS Perfect fit stabilizers make sure your Fitness Earbuds stay put even while you're on the move.  IPX7 WATERPROOF Tough conditions don't get in the way of your workouts, they definitely won't get in the way of your tunes because the Fitness Earbuds have IPX7 waterproofing.  54 HOURS OF BATTERY LIFE You don't have time to wait around for a charge, that's why the Fitness Earbuds have 54 Hours of Battery Life.  AWARENESS MODE Stay focused on your workout but in tune with your surroundings with Awareness Mode.  VIVID VOICE TECHNOLOGY Make your voice heard loud and clear even while you're breaking a sweat with Vivid Voice Technology.  THREE SOUND PROFILES Three Sound Profiles keep your workouts exciting by keeping the sound fresh. 3	QUICK START GUIDE 1. Take your earbuds out of the capsule. Both earbuds will connect to each other automatically.  2. From the source device, go to Bluetooth Settings, search for and select "The Fitness Earbuds" to pair.  3. Enjoy your Raycon Fitness Earbuds! 4	CHARGING YOUR DEVICE 1. Charging the Earbuds  Place Earbuds in the Capsule  Charging While charging, the lights on earbuds will be red, and the lights on capsule will be red  Fully Charged Your earbuds are fully charged when the lights on both your earbuds and capsule turn off Call / Play: About 9 hours Total battery life: About 54 hours 5	2. Charging The Capsule  Connect with Type-C cable  Charging While charging, the lights on the capsule will blink white.  Fully Charged When fully charged, lights will turn off. A fully charged capsule can completely recharge the earbuds up to 5 times before needing to recharge the capsule. Wireless Charging: Simply place the case on any Qi-compatible charging mat.
--	--	--	--	---	--	--	---	---	--	---

6

SOUND PROFILES Your sound, your way! As our sound profiles were crafted by artists and producers at the top of the industry, you're in good hands. PURE SOUND - Our most refined sound, perfect clarity to hear every single note. BALANCED SOUND - A leveled sound that is great for all around performance and warmth. BASS SOUND - Our bass boosted sound, great for songs with strong beats and a go-to for bass lovers.  Hold 1 for 3 secs to toggle between Sound Profiles AWARENESS MODE AWARENESS MODE Hear what's happening around you.  Hold 2 for 3 secs to toggle Awareness Mode On/Off	HOW TO CHANGE GEL TIPS Choose and install the gel tip that gives you the most comfortable and secure fit. Flip the gel tip inside out.  Align gel tip with earbuds and insert it.  Flip the gel tip back to front.  Make sure it is securely attached before you use. 	HOW TO CHANGE STABILIZERS Ensure the stabilizer corresponds with the correct earbud.  Secure the inner hook of the stabilizer into the groove at the top of the earbud.  Guide the stabilizer into place.  Ensure stabilizer is fully secure before use. 	GEL TIPS XS M L XL Select the right size gel tip for your ear. Keep gel tips clean to ensure a great listening experience. PERFECT FIT STABILIZERS XS M L Select the right size stabilizer for your ear. THE PERFECT FIT SHOULD LOOK LIKE THIS  Insert the earbuds into your ear.  Rotate the earbuds slightly forward.  The perfect fit should look like this. 11	SAFETY GUIDELINES Please follow the safety guidelines below at all times when operating or caring for your device. -Be wary of any edges, uneven surfaces, and metal parts, including on accessories and product packaging, to prevent any possible injury or damage. -Listen to music at a proper volume to avoid damaging your hearing and the earbuds. -Do not store in high temperatures, such as in a hot vehicle or in direct sunlight. -Do not expose the earbuds or any of its supplied parts to rain or other liquids for extended periods of time. Follow IPX7 Rating Guidelines. -If wet or submerged, please wipe dry as best possible before charging earbuds or capsule. -Do not drop or cause undue impact to the earbuds. -Do not modify, repair, or dismantle the product on your own. -Do not use any diluent or volatile liquid to clean the product. -Do not use the product in a hazardous location.	FAQ & ADDITIONAL RESOURCES Visit: www.rayconglobal.com/support. SUPPORT If your device is not functioning correctly, please visit www.rayconglobal.com/support for customer support, and we will be more than happy to help you. LIMITED WARRANTY Visit: www.rayconglobal.com/warranty. SPECIFICATIONS Model Number: RBE745 Bluetooth Name: The Fitness Earbuds RDID: D745-21E-Q321 Bluetooth Version: 5.2 Power Input: DC 5V/1A Capsule Battery Capacity: 3.7V/600mAh Call / Play Time: About 9 hours Charging Time: About 1 hour Support Profiles: HSP/HFP/A2DP/AVRCP Sensitivity: 102±3dB Frequency Response Range: 20-20000Hz Bluetooth Range: Up to 10 Meters	FCC WARNING This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: - Reorient or relocate the receiving antenna. - Increase the separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure statement. The device can be used in portable exposure condition without restriction	IC Caution: - English: This device complies with Industry Canada licence-exempt RSS standard(s). Operation is subject to the following two conditions: (1) This device may not cause interference, and (2) This device must accept any interference, including interference that may cause undesired operation of the device. - French: Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence. L'exploitation n'est autorisée aux deux conditions suivantes: (1) l'appareil ne doit pas produire de brouillage, et (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.  FCC ID: 2A20V-RBE745 IC: 27185-RBE745	 @rayconglobal
---	---	---	--	--	--	---	--	--