PURE

Elan One
DAB+ & FM radio with Bluetooth®

Quick Start Guide

Full user guide @ **support.pure.com**

| EN	DE	FR	IT	DA	NO
NL	ES	SV	CS	PL	PT

Alarms and timers

Set an alarm

1. Press Menu and turn and press Select dial to select 'System Settings'

Digital Radio	10:27
Station List	>
Full Scan	
Manual Tune	>
Prune	
DRC	>
System Settings	>

2. Turn and press Select dial to select 'Alarm'

System Settings	10:27
Kitchen timer	>
Sleep	>
Alarm	>
Equaliser	>
Time/Date	>
Backlight	>
Language	>

Menu

3. Turn and press Select dial to select 'Alarm 1' or 'Alarm 2'

Alarm	10:27
Alarm 1	>
Alarm 2	>

4. Turn and press the Select dial to adjust an alarm setting

Alarm 1 Details	10:27
Alarm	On
Frequency	Weekdays >
Wake Up time	06:30 >
Source	Buzzer >
Duration	60 >
Volume	6 >

Cancel an alarm

3 sec

```
                        10:27 🔋

                ⏻

            Alarm off
    ⚠                        📶
```

Snooze an alarm

```
                        10:27 🔋

                ⏻

            Snooze
    ⚠ 07:30                   📶
```

Set sleep timer

Menu

Digital Radio	10:27 🔋
Station List	>
Full Scan	
Manual Tune	>
Prune	
DRC	>
System Settings	>

System Settings	10:27 🔋
Sleep	>
Alarm	>
Equaliser	>
Time/Date	>
Backlight	>
Language	>
Factory Reset	>
Software upgrade	>
Software version	>

```
Set Sleep Timer        10:27 🔋

                🌙

            15 minutes
    🌙 15                     📶
```

1. Unclip (A) and extend aerial (B) and connect power to USB adapter (C)

USB A

Input: 5V ⎓ 2.0A

2. Push ⏻ to switch on

○ PURE

1 2 3+ ⏮ ⏯ ⏭
Stations

Menu   Info
Back   Source

⏻

Bluetooth

3. Wait for autotune to complete

Full Scan   10:27 🔋

Scanning…

Stations: 54

▮▮▮▮▮▮▮▮

▾⦿⦿⦿⦿

4. Press Source button to display Source menu

5. Tap Source button to switch between (A) DAB radio, (B) FM radio and (C) Bluetooth (See 'Choose Source' for more information)

Source

A   **B**   **C**

Digital Radio

Controls

Tap to turn Elan on and long press for standby (off when powered by batteries)

Switch between digital radio, FM radio & Bluetooth

Source

Change settings (including language)

Menu

Press to return to the previous screen

Back

Press to change radio stations

Stations

Set and recall presets

1

2

3+

Turn and press to select menu options. If listening to content, turn to adjust the volume & tap to mute the volume.

**Rear panel connections**

Micro USB Power input (software updates)
**500mA - 2.0A**

Input: 5V ⎓ 2.0A

Stereo headphone output (3.5mm)

Choose source

Digital radio

Change digital radio station

Stations

Station list	10:27
BBC Radio 1	
BBC Radio 1Xtra	
BBC Radio 2	
BBC Radio 3	
BBC Radio 4	
BBC Radio 5 Live	
BBC Radio 6Music	

FM radio

Seek to next station

⋈ **Statio** ⏱**3**sec	FM 10:27 🔋 **98.80MHz** 📻 Buzz FM Y.ıll

Manual tune

⋈⋈ ⋈ **Statio**	FM 10:27 🔋 **98.85MHz** 📻 Y.ıll

Bluetooth

Pair with a Bluetooth device

Bluetooth   10:27 🔋   ✳   14-7-2017 Friday Connected

Preset 1-2

Store

3 sec

Select

Preset 3-20

Store

2 sec 3+

Save to Preset 10:27
1: (Empty)
2: (Empty)
3: (Empty)
4: (Empty)
5: (Empty)
6: (Empty)
7: (Empty)

10:27

✓

Preset 5 saved

Select

3+

Preset Recall 10:27
1: (Empty)
2: (Empty)
3: (Empty)
4: (Empty)
5: BBC Radio 2
6: (Empty)
7: (Empty)

Digital Radio 10:27

BBC Radio 2

DAB

Pop Music

Digital radio settings

Autotune

Menu

Digital Radio 10:27
Station List   >
Full Scan
Manual Tune   >
Prune
DRC
System Settings   >

Full Scan 10:27

Scanning...
Stations: 54

Warranty information

Pure International Limited warrants to the end user that this product will be free from defects in materials and workmanship in the course of normal use for a period of two years from the date of purchase. This guarantee covers breakdowns due to manufacturing or design faults; it does not apply in cases such as accidental damage, however caused, wear and tear, negligence, adjustment, modification or repair not authorised by us. Please visit www.pure.com/register to register your product with us. Should you have a problem with your unit please contact your supplier or contact Pure Support at the address shown on the rear of this manual.

Specifications

Radio Digital (DAB/DAB+): Frequencies Digital Band III 174–240 MHz

FM radio: Frequencies FM 87.5-108 MHz (with RDS)

Bluetooth: Frequency range: 2402 < 2480 MHz, Maximum power: 4.0 dBm (EIRP), A2DP support.

Display: 2.4", 320 x 240, TFT colour display

Software version: 1A4

Speaker: 2.5" full range driver, 3 Watts output

Input connectors: Micro USB, Micro USB to USB A cable included

Output connectors: 3.5mm stereo headphone socket

Power supply requirements: 5V DC, 500mA - 2.0A or 4x AA batteries

Dimensions: W:175mm x H:106mm x D:54mm

Weight: 0.45kg

PURE

www.pure.com

support.pure.com

Pure International Limited
Concept House
Home Park Road
Kings Langley
Herts, WD4 8UD
United Kingdom

Pure Europe GmbH
Möslbichl 78
6250 Kundl
Austria