

修改内容	工程师	审核	日期	版本
初版设计声音模式改了	张维		2020-6-12	V1.0

展开尺寸：425x120mm,折叠尺寸：85x120mm; 材质：128g铜版纸 虚线为折痕

正面

59S® UVC LED STERILIZING BOX

S2
User Manual

INTRODUCTION

This is a fast sterilizing storage box powered by UV LED technology.
One-click to achieve 99.9% sterilization rate within just 180 Seconds.

The diagram shows the box from two perspectives: closed and open. Callout 1 points to the top lid's indicator window. Callout 2 points to the power button on the side of the closed box. Callout 3 points to the power switch interface on the front of the open box. Callout 4 points to the internal UVC LED array in the lid. Callout 5 points to the tool holder compartment in the base. Callout 6 points to the internal tool holder compartments in the lid.

- ① Indicator
- ② Sterilizing Button
- ③ Power Supply Interface
- ④ UVC LEDs
- ⑤ Tool Holder

HOW TO USE

1.Plug in the default power adaptor.

2.Put into items that are to be sterilized.
(Please keep all items tiled without overlapping.)

- 3.Press the sterilization button to start disinfecting automatically.
- 4.Keep pressing on sterilization button for 2 seconds to turn on/off the device.

- 5.Once sterilization process completes,the ring indicator will be solid on.It's available to take out the items.
- 6.The device will enter into sleeping mode without further operation in 5 mins. Pressing sterilization button to activate use once again.

APPLICATION

Sterilization for any of surfaces,such as shaver,nail scissors,glasses,cosmetic tools,etc.

SAFETY PROTECTION

Built-in particular safety switch,the UV LED light will be shut off once the sterilizing box is opened.

STERILIZATION PRINCIPLE

UVC LED light kills bacteria by destroying DNA or RNA,to stop them from reproducing and generating.

UVC LED DEODORIZATION

UVC waves can deodorize by decomposing the molecular structure of odor.

INTRODUCTION OF BACTERICIDAL FACTORS AND MICROORGANISM CATEGORIES

The main bactericidal factor and its intensity: UVC light,the average irradiance at a vertical distance of 0 cm and 3.7cm below the top UVC LED is respectively 2154μW/cm² and 105μW/cm²; killing microorganisms: Escherichia coli, Staphylococcus aureus.

INDICATOR STATEMENT

SN	Working Status	Indicator
★	Start up	Solid On
★	Standby/ Sterilization completes	Solid On
★	Sterilizing	Flickering

VOICE REMINDER

Sound prompts when pressing sterilization button and in sterilizing process.

反面

TECHNICAL PARAMETERS 1. Product Name: 59S[®] SZH8-S2 UVC LED STERILIZING BOX 2. Model: S2 3. Input: 10V  700mA(Default power adapter) 4. LED Beads: 8 pieces 5. Dimension: 216x105x70mm 6. Net Weight: 420g 7. Wavelength: 260-280nm 8. Power Supply Interface : Type-C USB 9. LED Lifespan : 10000 hours 10. TEMPERATURE : Working Temperature: 0~40℃ Storage Temperature: ~20~55℃	WARM TIPS 1. The machine is built-in with gravity sensory module, any noise generated during shaking or transportation attributes normal. 2. The machine is integrated with power-saving function, it will shut down automatically after standby for 15 hours. 3. Use the default adaptor for power supply, otherwise the product will get damaged. 4. Keep operation away from strong magnetic field objects. 5. Remove the mold smell of cosmetic tools, it will be more obvious when you sterilize for few times more according to the concentration of the odor. 6. Study the manual carefully and thoroughly, keep it properly.  CHILDREN PROHIBITED  NO TRAMPLING  DO NOT EXPOSE TO EYES & SKIN  NO WASHING & SOAKING	NAME AND CONCENTRATION OF HARMFUL SUBSTANCE OR ELEMENTS <table> <tr> <th rowspan="2">Part Names</th><th colspan="7">Harmful substance or elements</th></tr> <tr> <th>Pb</th><th>Hg</th><th>Cd</th><th>Cr(VL)</th><th>PBDE</th><th>PBB</th><th>EFUP</th></tr> <tr> <td>Shell</td><td>o</td><td>o</td><td>o</td><td>o</td><td>o</td><td>o</td><td>10</td></tr> <tr> <td>PCBA</td><td>x</td><td>o</td><td>o</td><td>o</td><td>o</td><td>o</td><td>10</td></tr> <tr> <td>USB Cable</td><td>o</td><td>o</td><td>o</td><td>o</td><td>o</td><td>o</td><td>10</td></tr> </table> O: It means that the concentration of the toxic and harmful substance in all homogeneous materials of the component is compliance with the limitation stipulated in GB/26572-2011. X: The concentration of the toxic and hazardous substances in certain homogeneous material of the component exceeds the limitation specified in GB/26572-2011. Note: Components marked "X" stands for no alternative technologies or components available at this stage. The EFUP refers to the safety lifespan of using the product without hazardous material leakage under the conditions specified in the manual.  For the product : 10 years EFUP under normal use conditions	Part Names	Harmful substance or elements							Pb	Hg	Cd	Cr(VL)	PBDE	PBB	EFUP	Shell	o	o	o	o	o	o	10	PCBA	x	o	o	o	o	o	10	USB Cable	o	o	o	o	o	o	10	WARRANTY Warranty Details Thank you for purchasing our product. In order to offer you good experience and protect your rights, we provide after-sales service in accordance with regulations & requirements by MII and AQSIQ. The following circumstances are not covered by warranty: - Warranty expires. - Malfunction or damage resulted from failure to use, maintain or keep the machine as instructed by the User Manual. - Disassemble the machine by customers without permission. - Malfunction or damage caused by human errors (such as misuse, collision or wrong voltage input). Product Model: _____ Date of purchase: _____ Dealer: _____ User name: _____ Phone number: _____ User address: _____ ▲ This voucher serves as an important evidence to resort for after-sales service and shall be kept properly.	 The Pioneer of LED Sterilization Manufacturer/Importer: Shenzhen UVLED Optical Technology Co., Ltd. Address: Room 307, FL 3, Phase 1, Bangkai Science and Technology Park, West of Bangkai Road & South of Guangang Road, Guangming Hi-Tech Industrial Zone, Tangjia Community, Phoenix Street Admin, Guangming District, Shenzhen, China Commissioned Manufacturer: Shenzhen UV Guard Technology Co., Ltd. Factory Address: 3-4/F, Building 2A, No.9, Bangkai Road, High-tech Industrial Park, Guangming District, Shenzhen, China Hygienic License: YWZZZ(2018)-02-No.9142 Post Code: 518132 Executive Standard: Q/YCHC 002 https://www.59s.com
Part Names	Harmful substance or elements																																										
	Pb	Hg	Cd	Cr(VL)	PBDE	PBB	EFUP																																				
Shell	o	o	o	o	o	o	10																																				
PCBA	x	o	o	o	o	o	10																																				
USB Cable	o	o	o	o	o	o	10																																				
PACKING LIST  Sterilizing Box *1  Tool Holder *1  Power Adaptor (Type-C USB Cable) *1  User Manual *1  Sterilization Testimonial *1																																											

物料编号	50.11.S2E30000R	产品型号	S2-E纯英文说明书
电子		品名	LED紫外线消毒盒S2-E纯英文说明书（59S Logo）"R"商标/消毒时间3分钟/材质:128 铜钢板纸/85*120mm/V1.0
认证			
文档		钰小将 YUXIAOJIAO 深圳市钰小将智能科技有限责任公司	